



JASMINE AVENUE				
PARCEL	DESIGN	"AS BUILT"	BACKFLOW PREVENTER	MODIFIED WYE
1	23+26		<i>N</i>	<i>Y</i>
2	21+62		<i>Y</i>	<i>N</i>

1. INSTALL 4" DIAMETER MANHOLE PER CITY OF FONTANA STD. DWG. 112.
2. INSTALL 8 INCH DIAMETER EXTRA STRENGTH VCP SEWER LINE.
3. INSTALL 6 INCH (FLAT) SEWER LATERAL WITH PL CLEANOUT PER CITY OF FONTANA STD. DWG. 125 WITH SEWER CLEANOUT BOX PER CITY OF FONTANA STD. DWG. 125 B.
4. REMOVE EXISTING 8" PLUG.
5. REINFORCED CONCRETE ENCASEMENT PER DETAIL "A" PER SHEET 2.
6. SAWCUT AC REMOVAL AND TRENCH RESURFACING PER CITY STD. # 131.
7. INSTALL 6 INCH SEWER LATERAL WITH PL CLEANOUT PER CITY OF FONTANA STD. DWG. 125 WITH SEWER CLEANOUT BOX PER CITY OF FONTANA STD. DWG. 125 B.
8. INSTALL 8 INCH DIAMETER DIP SEWER LINE.

ALL WORK ON STREET RIGHT-OF-WAY SHALL NOT COMMENCE UNTIL A CONSTRUCTION PERMIT HAS BEEN ISSUED.

PRIOR TO CONSTRUCTION, THE CONTRACTOR SHALL VERIFY THE HORIZONTAL AND VERTICAL POSITION OF ALL POINTS OF CONNECTION TO EXISTING STRUCTURES. THIS SHALL INCLUDE BOTH ABOVE GROUND AND BELOW GROUND POINTS OF CONNECTION. THE ENGINEER SHALL BE NOTIFIED OF ANY DISCREPANCIES PRIOR TO THE BEGINNING OF CONSTRUCTION.

